




Mounting Options

Decide between Inside Mount (IB) or Outside Mount (OB). See below for description.

INSIDE MOUNT (IB)




Please note this installation may cause light gaps on either side of the shade.

If a shade is mounted between two walls it is considered Inside Mount.

Also if sufficient depth is not available the shade unit may protrude past the opening.

OUTSIDE MOUNT (OB)



Sun Or Shade · 5725 Avery Road · Dublin · OH · 43016
800.742.3372 · www.sosshades.com

WE'RE ON A ROLL





Inside Mount (IB) Instructions

NEEDED

Steel Tape Measure
Ladder of appropriate height for your windows

TIPS

Provide measurements to the nearest 1/8"
Measure every window
Always measure in three places for width and length.
1. Top 2.Center 3. Bottom


WIDTH: Measure inside width of window opening at the top, center, and bottom to the nearest eighth of an inch (1/8").

Submit narrowest measurement.


LENGTH: Measure the inside height of the window opening at the left, middle and right to the nearest eighth of an inch (1/8").

Submit the longest measurement.


DEPTH: Measure the depth of the window at the top on each side. **Submit the smallest measurement.**



Measure Top, Middle, and Bottom



Measure Window Depth





Outside Mount (OB) Instructions

NEEDED

Steel Tape Measure
Ladder of appropriate height for your windows


TIPS

Provide measurements to the nearest 1/8"
Measure every window
Always measure in three places for width and length.
1. Top 2.Center 3. Bottom



OUTSIDE MOUNT

WIDTH: Measure width of window opening at the top, center, and bottom to the nearest eighth of an inch (1/8"). Add sufficient overlap to satisfy design considerations. **Submit widest measurement.**

LENGTH: Measure height of window opening at the left, middle and right to the nearest eighth of an inch (1/8"). Add sufficient overlap to satisfy design considerations. **Submit longest measurement.**



Measure Top, Middle and Bottom







End To End (ETE) Instructions

END TO END (For Multiple Shades Over One Opening)

WIDTH: Measure along window to the desired shade width, typically this is to the center of the mullion. On the measure form make notations for the number of shades in each group, especially if one valance is used to cover all shades. Also note if they will be Inside Mount or Outside Mount.

END TO END INSIDE MOUNT (ETE-IB):



END TO END OUTSIDE MOUNT (ETE-OB):

